

Installation guidance

Gyproc® Drywall Primer

Roller application

Step 1



After joint treatment is complete, clean down boards and ensure they are free from dust

Step 2



Stir before use

Step 3



Apply with a brush or medium pile roller

Step 4



Wait until dry and then begin decoration

Note:

Gyproc Drywall Primer may be used as a base for most wallcoverings, but solvent-based wall covering adhesives should not be used.

If steam stripping resistance or a vapour barrier is required use Gyproc Drywall Sealer instead.

**Times and processes are given as guidance.
On site practice may vary.**