

Installation guidance

Gyproc® SoundCoat Plus

TIMES ARE APPROXIMATE

0 mins



Add 17.5 litres of clean water per 25kg bag to a clean mixing bucket. Gradually add the powder while mixing

5 mins



Leave to rest for 5 minutes before applying

5 - 40 mins



Apply to a 6mm depth to entire surface ensuring all cracks or unfilled voids are covered

There is no need to trowel smooth

60 mins



Allow minimum 60 mins setting time before fixing plasterboard to surface with Gyproc DriWall Adhesive

Note:

Working time is approx 40 mins.

Times and processes are given as guidance. On site practice may vary.



Finishing times are **reduced** by suction



Finishing times are **extended** by cold weather conditions