

# Installation guidance

ThistlePro® DuraFinish

TIMES ARE APPROXIMATE

## 0 mins



Add approx 11.5 litres of clean water to per 25kg bag to mixing bucket. Gradually add the plaster to water whilst mixing. Mix slightly wetter than other Thistle plasters. Mixture stiffens slightly after mixing. Once mixed, leave the product to sit for 5 mins, then re-mix a final time before applying



Complete 1<sup>st</sup> coat (1mm thick)

## 20 - 45 mins



Complete 2<sup>nd</sup> coat, the total thickness for both coats should be a minimum of 2mm

## 45 - 65 mins



Closing in  
**Important:** Get as flat as possible at this stage to aid trowelling later. Do not use water at this stage, a wet trowel should be used

## 90 mins



1<sup>st</sup> trowel

## 115 mins

2<sup>nd</sup> trowel

## 135 mins

Final trowel to a matt finish (lubricated with minimal water)

### Note:

Ensure that the product is suitable for the background to which it is being applied by using the Thistle Plaster Selector Guide.

The working characteristics of ThistlePro DuraFinish differ from other Thistle finishing plasters. See guidance detailed to the left for more information.



Finishing times are **reduced** by suction



Finishing times are **extended** by cold weather conditions

**Times and processes are given as guidance. On site practice may vary.**