

Installation guidance

Thistle® GypPrime

Roller application

Step 1



Prepare the surface by cleaning, backgrounds should be reasonably dry, clean and dust-free

Step 2



Stir before use, dilute if preferred using a ratio of no more than 1 part Thistle GypPrime to 5 parts water

Step 3



Protect adjacent surfaces from splashes and remove any spillage before it dries

Apply with a roller or brush

Step 4



The surface can then be plastered when the Thistle GypPrime has soaked into background

Note:

Ensure that the product is suitable for the background eg high suction backgrounds.

See FAQs for specific guidance on dilution for different backgrounds.

Times and processes are given as guidance. On site practice may vary.