Installation guidance

Thistle® SprayFinish

TIMES ARE APPROXIMATE

0 mins

Spray-apply to an even thickness of approx. 2mm

5 - 10 mins

Within 10 minutes, flatten using a trowel or spatula, without removing material. Air trapped at this stage will be released later

40 mins

Gradually flatten and finish using the same techniques as hand-applied plaster

1st trowel

70 mins

2nd trowel

100 - 110 mins

Final trowel to a matt finish (lubricated with minimal water)

Note:

Ensure that the product is suitable for the background to which it is being applied by using the Thistle Plaster Selector Guide.

The most common way to mix and apply Thistle SprayFinish is using a worm pump plastering machine. To learn how to do this with your chosen machine, please refer to the machine manufacturer's guidance. In general, the plaster's consistency should be slightly softer than that used for hand application.

Finishing times are **reduced** by suction

Finishing times are **extended** by cold weather conditions

Times and processes are given as guidance. On site practice may vary.